

Roboty frezowania i wyrównania na całej szerokości jezdni i zatok

Kolumny 1, 2, 3, 4 oznaczają numery warstw liczone od góry.

Lokalizacja		Powierzchnia frezowania	O b j ę t o ś ć						Pole nawierzchni	Pole tworzyw (rusztów)
			frezowania	1	2	3	4	wyrównania		
km	m	m ²	m ³	m ³	m ³	m ³	m ³	m ³	m ²	m ²
0	386,36									
		10,798	1,026	2,182	5,456			3,470	54,56	
0	400,00	19,792	1,880	4,000	10,000			8,880	100,00	
0	425,00	0,000	0,000	5,600	14,000			20,580	140,00	
0	460,00	0,000	0,000	6,400	16,000			17,000	160,00	
0	500,00	0,000	0,000	8,000	20,000			10,750	200,00	
0	550,00	100,000	3,500	8,000	20,000			8,500	200,00	
0	600,00	70,000	2,450	5,600	14,000			2,800	140,00	
0	635,00	2,083	0,010	4,000	10,000			7,410	100,00	
0	660,00	37,095	2,191	3,200	8,000			4,350	80,00	
0	680,00	88,571	5,457	8,000	20,000			2,310	200,00	
0	730,00	0,000	0,000	4,800	12,000			6,600	120,00	
0	760,00	0,000	0,000	6,400	16,000			15,800	160,00	
0	800,00	0,000	0,000	8,000	20,000			14,000	200,00	
0	850,00	0,000	0,000	8,000	20,000			9,000	200,00	
0	900,00	0,000	0,000	8,000	20,000			17,500	200,00	
0	950,00	0,000	0,000	10,400	26,000			24,120	260,00	
1	15,00	0,000	0,000	8,800	22,000			16,830	220,00	
1	70,00	0,000	0,000	10,400	26,000			24,640	260,00	
1	135,00	0,000	0,000	7,200	18,000			16,830	180,00	
1	180,00	50,000	0,250	8,000	20,000			9,600	200,00	
1	230,00	50,000	0,250	8,000	20,000			11,350	200,00	
1	280,00	48,125	1,059	11,200	28,000			25,350	280,00	
1	350,00	44,687	0,983	10,400	26,000			16,390	260,00	
1	415,00	0,000	0,000	8,000	20,000			16,750	200,00	
1	465,00	0,000	0,000	9,600	24,000			25,800	240,00	
1	525,00	0,000	0,000	8,800	22,000			17,330	220,00	
1	580,00	0,000	0,000	8,000	20,000			11,000	200,00	
1	630,00	0,000	0,000	8,800	22,000			18,980	220,00	
1	685,00	111,240	2,225	8,899	22,248			14,460	222,48	
1	740,62									
Sumy:		632,39	21,28	216,68	541,70			398,36	5417,04	